



ACEMO  
30 RUE ALBERT DE MUN  
56300 PONTIVY. FRANCE  
Tel : + 33 2 97 25 05 30  
Fax : + 33 2 97 27 84 60

## ELECTRONIC WEIGHING INDICATORS

# DATAFARM 200 and 200M

## VERSION 1.06

### CONTENTS.

Safety procedures	Page 2
Installation	Page 4
Presentation	Page 11
User programming	Page 12
Installer programming	Page 13
Operating instructions	Page 14
Maintenance	Page 15
Appendix 1 and 2	Page 16
Wiring diagram of 3 digits indicator panel	Page 19

# SAFETY PROCEDURES



## SECURITY AND MAINTENANCE PRECAUTIONS

### COMPULSORY PROCEDURE BEFORE WORKING ON THE EQUIPMENT

Before carrying out any work of any sort, on either mechanical, electrical, or pneumatic components, it is compulsory to cut the energy supplies.

#### ⚡ ELECTRICAL SHUT-DOWN

a) Cut the main electrical supply, via the general cut-out means available( circuit-breaker, plug and socket, fuses...).

b) Lock the circuit-breaker in the OFF position.  
If possible, use a padlock through the holes provided in the switch lever.

It is important to be sure, that under all circumstances, nobody can switch the power back on again, before he that switched it off, has finished his work.

#### ⚡ PNEUMATIC SHUT-DOWN

- a) Close the tap on the main air-line.
- b) Padlock, if possible, in the closed position.
- c) Purge the air-lines.
- d) Check that the air-lines have no remaining pressure in them.



## IMPORTANT

During starting up operations, ALL the programmable values must be systematically checked and adjusted to the installations requirements.



The examples given in this guide are used to help understand the operations, but are not intended as representative values.

The measuring cells (temperature probes, load-cells, etc...) should be calibrated after several hours operation, and then periodically.

**ACEMO CANNOT BE HELD RESPONSIBLE for damages caused by:**

- Programming values that are unsuitable for the installation.**
- Bad maintenance.**
- Any eventual errors in this Manual.**

# DATAFARM 200 .



Cable gland layout .

- 1 à 4 - Load-cells
- 5 - Load-cell extension lead
- 6 - Unused
- 7 - RS232 serial link
- 8 - Earthing lead
- 9 - Power input

# INSTALLATION.

## FIXING :

The DATAFARM 200 control box should be situated inside a building, near the weighing platform or tank, and placed so that the LCD screen is easy to read with easy access to the unit.

The Load-cells connect directly to terminals inside the Datafarm 200. If the control box is too far away to do this, then an intermediate connecting box and a special cable can be added.


The Datafarm 200 is wall mounted, and should be fixed at a height of about 1m40 from the floor using either of the 2 following methods.

### 1) External fixing holes (A) :


- Open the box.
- Unscrew the 2 hinge fixing screws from the bottom part of the box.. (voir fig. 1).
- Remove the cover.
- Fix the bottom part of the box using 4 screws (not supplied), in each hole (A).
- Reassemble the cover and hinges.

### 2) Internal fixing holes (B) :

- Open the box.
- Fix the bottom of the box using 4 screws (not supplied) positioned in the holes (B).(see fig.2) .
- Push the 4 sealing covers over the heads of the screws.



**Figure 1.**



**Figure 2: Fixing holes on bottom of box.**

### **MAINS POWER SUPPLY.**

To guaranty correct and safe operation, the DATAFARM 200 must be installed and commissioned by qualified personnel in compliance with the specifications laid down in these operating instructions.

- Installed to national specifications.
- Rated supply voltage = 207 to 244 volts.
- Frequency 50 Hz.
- Grounded impedance lower than 5 Ohms
- Balanced potential along Ground line.

When using a Datafarm weighing indicator in conjunction with an electromechanical control panel the power to the Datafarm should come from this panel in order to profit from the overload protections.


## CABLING INSTRUCTIONS.

### 1) Inside the Datafarm 200:

- The cable shielding and the Ground leads must be connected to the Earth terminals.
- Use only one cable per cable gland:
  - Cable gland 7 => cable 3 to 6 mm.
  - Cable gland 9 => cable 5 to 8 mm.
- Cable lengths inside the box should be kept to a minimum.

### 2) Outside the Datafarm 200 :

- Use a metallic cable-run to fix the cables linking different elements of the same installation (load-cells, junction boxes, Datafarm 200, electromechanical control panel, computer ).
- A mild-steel perforated cable-run is better than a version made from wire frame.
- The link between each section of cable-run should be made using the correct joining pieces to ensure a good metal to metal contact.
- If it is impossible to use a metallic cable-run, then this must be replaced by a separate green and yellow cable of at least 6mm<sup>2</sup> section.
- In an open metallic cable-run, power lines and signal lines can coexist on the condition that they are separated by at least 5cm. If they are not in a cable-run then they should be separated by at least 20cm.



- Connect a 6mm<sup>2</sup> section yellow and green cable between each load-cell support and the cable-run that holds the load-cell cables running to the Datafarm 200.
- If the load-cells are all mounted on the same metallic chassis , connect a single 6mm<sup>2</sup> section yellow and green cable between the chassis and the cable-run. – Appendix 1 illustrates these recommendations.

## CABLE CHOICE :

DATAFARM 200 terminals	Cable gland number	Voltage / Current	Type	Cable characteristics	Reference
Load-cell connection J1 to J4 on connecting board . J1 on circuit board CPUPES1 ( +5V , IN+ , IN- , -5V ) .	1 to 4 5	10V / 20 mA	Signal	Cables on load-cells 5x 0,5 shielded copper braid	M811915
RS232 serial link R-0V-T on board CPUPES1	7	± 12V / 20 mA	Signal	2 pair shielded copper braid	M811912
Mains N-EARTH-L	9	207 - 244V / 50 mA	Power	- 3 x 0,4mm <sup>2</sup> mini - 3 x 1,5mm <sup>2</sup>	
GROUND LINE	8			1 x 6mm <sup>2</sup> green/yellow (mini)	

Table N°1

## CONNECTION TO MAINS SUPPLY.

The Earth lead should be as short as possible and connected to the metal back plate.

? **For the Datafarm 200 :**

Connect to Mains terminals on CPUPES1 circuit board.

? **For the Datafarm 200 M .**


Connect to Mains terminals on ENSO-P 1 relay board.

## LOAD-CELL CONNECTIONS.

? **Never cut the load-cell cables .**

? **Load-cells close to Datafarm :**

The load-cells are wired directly inside the Datafarm200 on the connection board.  
(See chapter “ Connections and Load-cell sensitivity ”)




Note : The shielding braid from the load-cell cables is connected to the metal base plate in the box.

**? Load-cells at a distance from the Datafarm 200:**

The load-cells are connected via an intermediate connection box containing the load-cell connecting board that is recuperated from inside the Datafarm 200.

A specific extension cable (Ref.: M818515), is then used to link the connection box to the Datafarm 200. (See chapter “ Connections and Load-cell sensitivity ”).



**CONNECTIONS AND LOAD-CELL SENSITIVITY.**

Load-cell \ Datafarm	+ 5V	IN+	IN-	- 5V	Sensitivity
Sensy 5510	brown	green	white	yellow	2 mV/V
Sensy 4500	brown	green	white	yellow	2 mV/V
Sensy 4500	grey/brown	pink	white	yellow/green	2 mV/V
Sensy 4000	brown	green	white	yellow	1 mV/V
Sensy 2000 (50kg)	grey/brown	pink	white	yellow/green	2 mV/V
MOBA	b 4*	c 3*	a 2*	d 1*	0,8 mV/V
Sensy 202L (300kg)	brown	green	white	yellow	2 mV/V
MCBU	green	red	white	black	3 mV/V
Captel 1,5T CAX1.5	black	green	white	red	2 mV/V
Captel 3T CAX3.0	green	brown	white	yellow	2 mV/V
Sensy 2712 (30kg or 20kg)	brown	green	white	yellow	2 mV/V
Man 300kg	green	red	black	white	2 mV/V
Adaptor Datafarm 200	black	brown	grey	blue	

\* Terminal N° on MOBA connectors.

This table gives the wiring connections for most of the load-cells used by ACEMO to date. For any other model, please contact us.


**SERIAL LINK CONNECTIONS.**

- This concerns an RS232 serial link, as follows:
  - 1200 baudrate
  - 1 start bit
  - 1 stop bit
  - No parity


The link transfers the weight value to a computer, either permanently ( data flow ), or on request ( data request ).

Connect the transmission cable to terminals R , 0V , T " Serial Liaison " on the CPUPES1 circuit board.

**a) Multifarm computer connection:**




**b) MR88 computer connection:**




**RELAY CONNECTION FOR THE VERSION 200M.**

A relay with a floating on/off contact, is set with a value programmed by the user.  
Two operating modes are possible:

**1) Loading mode .**




**2) Unloading mode .**



the choice between loading and unloading is programmed with the parameter "CONSI" when the Datafarm is in 'User' mode.

The hysteresis value is programmed when the Datafarm is in 'Configuration' mode.



Floating contact relay 250V , 2A maxi



## USER PROGRAMMING

### User mode

- When the power to the Datafarm 200 is switched on, the screen at first indicates " 8.8.8.8.8. " during a couple of seconds, and then the software reference. After this initialisation, the weight on the load-cells appears on the screen and on the serial link. The user can then either effectuate an 'Add-on' weighing, modify the Tare or relay trip value, or using a code, enter into the 'configuration' programming.

" **ADD-ON WEIGHING** " - Add the load to be weighed . The screen will show the weight of the load that has been added. Pushing the key "minus" will reset the indicator to zero and the relay is activated for a new loading or unloading .

**Remarks :** The weight shown on the screen after pushing the "minus" key will blink to inform the user that the Datafarm is in 'Add-on' mode. Pushing the "plus" key to pass more from Add-on" mode to original weight and conversely. During 'Add-on weighing' the weight transferred along the serial link corresponds to the total weight on the scale.

" **TARE** " – This operation allows the user to adjust the value on the screen of the Datafarm to the real weight on the scale .To do this : ? Empty the tank or hopper, select 'Tare' mode via the keys, adjust the value, then validate.


" **CONSI** " – This concerns only the Datafarm 200M. These versions are equipped with an ENSO-P circuit board, with an operating mode as "loading" or "unloading":

∞ loading mode if the value is positive (example: 50).


∞ unloading mode if the value is negative (example -50).

Via this operation the datafarm200M determines the value at which the relay will switch.

#### 1) Operating mode = loading



#### 2) Operating mode = unloading



" **CONF1** " : After entering and validating the code '38' the Datafarm enters into the 'Configuration' mode.

**Attention ! :** This operation should only be carried out by a qualified technician.

To leave this mode, simultaneously push the "+" and "-" keys.

### Under certain conditions an error message may appear on screen.

Message	Meaning	Cause
Err.2	overload	Badly connected load-cells
Err.3		Load-cells overloaded
Err.4		Load-cell not working
Err.5	Conversion error	Datafarm not working

# INSTALLER PROGRAMMING.

## The 'Configuration' mode.

- Installer programming is possible only when the Datafarm200 is in 'Configuration' mode. To enter this mode, from 'User' mode, select the heading " CONF1 " then write and validate the number " 38 ". To return to user mode, push simultaneously on keys " + " and " - "
- Each push on the " P " key, will advance the reader to the next value. To modify a value, see chapter " Key Use ". This mode is reserved for the use of the Installer or After-sales technician.

## Description of different functions:

- " **Brut** " : Gross weight, result given by conversion This value is between 0 and 99999.
- " **Coef A** " : Coefficient A , this value is either factory set, or can be modified during installation, and depends on the amplifier gain (1mV/V to 2mV/V) , the amplifier coefficient used, and the type of load-cells installed. If the Load-cell coefficient is known, it can be obtained by calculation, if not, it must be obtained experimentally
- **By calculation** :  $\text{Coefficient A} = \text{Amplifier coefficient} * \text{Load-cell coefficient}$  .  
The amplifier coefficient depends on the CPU PES1 circuit board, and is written on this board.  
The Load-cell coefficient is given by the table "Load-cell characteristics " in appendix 2.
- **Experimentally**:  
1) Choose the weight unit (kilograms, hectograms, decagrams, or grams) that best represent the maximum load on all the load-cells, using a maximum of 5 digits.  
Examples:       \* 10000 kg       - > 10000 kg  
                  \* 4500 kg       - > 45000 hectograms  
                  \* 300 kg- > 30000 decagrams  
                  \* 10 kg         - > 10000 grams
- 2) Use a known weight, that represents at least 25 % of the total capacity of the sum of the Load-cells. The value of this weight must be converted into the same units as those selected above.

Delta points = 'Brut' weight with load added – 'Brut' weight without load  
 Coeff A = Known weight / Delta points

Examples:

Max.Scale value	Weight Unit	Known Weight	Result for Coeff. A
10000 kg	kilogram	3000 kg	3000 / (delta points)
4500 kg	hectogram	1200.5 kg	12005 / (delta points)
300 kg	decagram	70.23 kg	7023 / (delta points)
10 kg	gram	9.67 kg	9670 / (delta points)

3) Adjust the position of the decimal point in order to read in kilograms (see " **Affich** ")

- " **Coef B** " : Coefficient B. This value is the result of the 'Tare' operation carried out in the User mode, and cannot be modified in this programme.

$$\text{Weight indicated on screen} = \text{Coeff A} * \text{'Brut' weight} - \text{Coeff B}$$

- " **Echel** " : Scale. This value ( 01 , 02 , 05 , 10 , 20 , 50 ) represents the step between 2 consecutive values. It has been factory set to suit the type of Load-cells.

- " **Filtr** " : Filter. This value ( 04 , 08 or 16 ) represents the filtering amplitude. Again, it has been factory set to suit the type of Load-cells. For pig weighing platforms (mode = "P"), this value isn't used, as the filtering is automatic.

- " **Affich** " : Display. This value ( 0 , 1 , 2 , 3 ) indicates the position of the decimal point, in order to display the weight on screen in kilograms. It has been factory set to suit the type of Load-cell.

- Affich = 0 > If weight unit is in kilograms
- Affich = 1 > If weight unit is in hectograms
- Affich = 2 > If weight unit is in decagrams
- Affich = 3 > If weight unit is in grams

- " **DATA** " : This value determines the operation mode of the RS232 data link between Datafarm200 and the computer.

r ? Data request (Multifarm) .

F? Data flow (MR88) .

p ? Transmission to a 3 digits indicator panel .

Indicator mode:

- 1 - The weight value is between 0 and 999 :  
the weight appears normally on the 3 digits screen .
- 2 - The weight value is higher than 999 :  
the weight appears using in a sequence corresponding to 2 digits for tons , and then 3 digits for the remaining kilograms . The ton value appears on screen for half a second, the kilogram value then appears 2 seconds .
- 3 - The weight value is negative :  
the panel indicates a blinking '888' sequence .

- " **Mode** " : This value sets the operating mode of the Datafarm 200:

- "0" : Standard weighing mode,
- "P" Pig weighing platform mode,
- "d" Unloading mode, (Not used in version 1.06)
- "c" Loading mode. (Not used in version 1.06)

- " **Hyst** " : Hysterisis: Value in Kg, between 0 and 9999, indicating the Hysterisis value applied to the relay trip value, to prevent the relay swinging back and forth when the weight reaches the chosen value.

- " **REL1** " : Simulates relay activation:

? "ON" = Relay activated ,?"OFF" = Relay at rest .

### **Reset of EEprom memory.**

To reset the memory, the " - " key must be pushed 5 times during the initialisation period, while the software version is on the screen.

After a memory reset, all values that have manually programmed are replaced by the factory determined values.

## **OPERATING INSTRUCTIONS.**

- Read through the entire manual carefully.
- Carry out the electrical connections.
- Adjust the 'Tare' after several hours operation.
- Check the weight indicated on the screen by using a known value representing at least 20% of the nominal load.
- Check the operation of the serial link, if connected.
- For the 'M' version.
  - Programme a 'Set Value' .
  - Programme the Hysterisis value.
  - Select the operation mode.
  - Carry out a test, to validate the data entered.

## **MAINTENANCE :**



- Before cleaning the control box, ensure that the safety precautions have been respected and that the electricity supply has been cut correctly (see page 2).
- Keep the control box and load-cells clean using only a damp sponge. Do not use detergent or solvents, and do not use either a hose or a high-pressure washer.
- A weighing system under a tank or hopper should have its tare weight checked once a month by the user.
- The calibration is controlled during starting-up operations, and then a minimum of once every 6 months, by a qualified and authorised service technician, using test weights (control empty tank and maximum load).

### **1) Removing the CPUPES1 circuit board:**

- Cut the power and follow the safety procedure (see page 2).
- Open the control box.
- Disconnect the terminals on the CPUPES1 board.
- Unscrew the 4 fixing screws.
- Remove the board .
- Replace with a new board, and carry out the above operations backwards.
- Switch the power back on.
- Check the operation and the programme values .

#### **- Important :**

Each time a CPUPES1 board is changed , it is necessary to:

- ? Run a calibration check.
- ? ? ? ? ? ? Programme all the data in 'Configuration' mode.
- ? ? ? ? ? ? Carry out a system 'Tare' (User mode).
- ? ? ? ? ? ? Check the weight on the screen using known weights .

### **2) Removing the ENSO-P circuit board:**

- Cut the power and follow the safety procedure (see page 2).
- Open the control box.
- Disconnect the terminals on the ENSO-P board.
- Unscrew the 4 fixing screws.
- Remove the board .
- Replace with a new board, and carry out the above operations backwards.
- Switch the power back on.
- Check the operation and the programme values .

### **3) Spare parts :**


Description	Reference
Temporised Fuse 100mA Size 5x20	M648512
CPUPES1 circuit board	EL0553
ENSO-P 1 relay board	EL0556
Load-cell connecting board	SC0343
Datafarm 200	10 40 00
Datafarm 200M	10 40 01
Load-cells	Depending on type

### **4) Accessories :**

Description	Reference
Box for load-cell connection board	10 40 02
Shielded load-cell extension cable	10 40 03Z
RS232 serial link cable	M811912

# CEM COMPLIANCE CABLE INSTRUCTIONS

## APPENDIX 1.



- - Detail A. The lower part of each Load-cell support is connected with an Earth lead to the metallic cable -run, keeping the
- A perforated metallic cable -run is to be preferred to a wire-framed version.
- Links between different sections of cable -run must ensure good electrical continuity.
- Cables should be laid and attached in the corners of the cable -run.
- If impossible to use a cable -run, it must be replaced by a green and yellow ground lead of at least a section of 6mm<sup>2</sup>.

**General reminder-** In a metallic cable -run, power cables and signal cables can coexist on the condition that they are placed centimetres between them.

## Appendix2

### LOAD-CELL CHARACTERISTICS

Type of Load-cell	Qty	Sensitivity	Scale	Filter	Display	Coef. load-cell
Sensy 5510/4500 500Kg	3	2 mV/V	02	08	1	0.7462
Sensy 5510/4500 500Kg	4	2 mV/V	02	08	1	0.9950
Sensy 5510/4500 1T	3	2 mV/V	02	08	1	1.4910
Sensy 5510/4500 1T	4	2 mV/V	02	08	1	1.9880
Sensy 5510/4500 1.5T	3	2 mV/V	02	08	1	2.1900
Sensy 5510/4500 1.5T	4	2 mV/V	05	08	1	2.8990
Sensy 5510/4500 3T	3	2 mV/V	01	08	0	0.4473
Sensy 5510/4500 3T	4	2 mV/V	01	08	0	0.5964
Sensy 4000 3T	3	1 mV/V				
Sensy 4000 3T	4	1 mV/V				
Sensy 202L 300Kg	1	2 mV/V	01	08	1	0.1588
Sensy 2712 20Kg	1	2 mV/V				
Sensy 2712 30Kg	1	2 mV/V				
Moba 300Kg	3	1 mV/V				
Moba 300Kg	4	1 mV/V				
Moba 3T	3	1 mV/V				
Moba 3T	4	1 mV/V				
MCBU	1	2 mV/V				
MAN 300Kg	1	2 mV/V	01	08	1	0.1434
Captel CAX 1.5 1.5T	3	2 mV/V	05	08	1	1.8769
Captel CAX 1.5 1.5T	4	2 mV/V	05	08	1	2.5025

**REMEMBER :** coefficient A = Amplifier coefficient \* Load-cell coefficient .

The Amplifier coefficient is written on the CPU PES1 board.

When the load-cell coefficient is unknown, an experimental calibration must be carried out using at least 25% of the nominal charge of the load-cells.

$$\text{Coef A} = \frac{\text{Weight of load}}{\text{Gross weight with load} - \text{Gross weight without lo:}}$$

# WIRING DIAGRAM OF A 3 DIGITS INDICATOR PANEL WITH A DATAFARM

